


Stainless Steel Level Control Faucet

Cleaning and Installation Instructions



Cleaning and Assembly

Step 1

Remove the nut from the threaded end of the faucet body, along with the two stainless steel washers and the two silicone washers. Remove the protective film from the stainless steel washers. Unscrew the top cap from the metal sleeve, being careful not to lose the silicone washer inside the cap. Place the glass tube in a safe place so it won't roll.

Step 2

Clean the parts with warm soapy water. **DO NOT LOSE THE SILICONE WASHER** located inside the top cap. The glass tube will leak if the rubber washer is not in place.

- Hand wash only. Do not wash in a dishwasher.
- A small soft brush can be used to clean the inside of the glass tube.

Step 3

- Rinse and dry all parts.
- Insert the glass tube into the stainless steel sleeve.
- (Optional) Insert the blue ball into the glass tube.
- Make sure the silicone washer is in the top cap.

TIGHTEN THE TOP CAP FIRMLY BY HAND.

- Proceed to installation.

Installation

Step 1

- Discard all water present in the upper and lower chambers and remove your existing faucet.
- Make sure the top cap is hand-tightened firmly. A leak may occur at the base of the glass tube if it is not properly secured.
- Place a stainless steel washer on the faucet threads and position it so that the beveled side faces away from the stainless steel chamber. (See image below)

Step 2

- Insert the threaded end of the fitting into the hole of the lower chamber of your Berkey system.
- Place the remaining silicone washer, then the remaining stainless steel washer on the faucet threads inside the lower chamber. Position the beveled side of the metal washer away from the hole of the lower chamber (see first image).
- Secure the plain end in place with the nut.

Step 3

- Make sure the rubber base ring of your Berkey System is not pinched by the outer washers of the faucet.
- When the faucet is open, the arm is straight. When the faucet is closed, the arm is pointed to the right. **TO AVOID LEAKS, MAKE SURE THE FAUCET IS IN THE CLOSED POSITION WHEN NOT IN USE.**
- Your level control faucet is now ready to use!

